

AT10.1/AT30 SERIES

MICROPROCESSOR-CONTROLLED FLOAT BATTERY CHARGER

FORCED LOAD SHARING OPTION

CONTENTS

Introduction.....	1
System Requirements	1
Installing the Interconnection Cable	2
Operating Chargers in Load Sharing	2
Interconnection Diagram.....	3
Using With Temperature Compensation	4
Trouble Shooting	4
Ordering Parts	4
Document Control Information.....	4

INTRODUCTION

Multiple battery chargers are sometimes employed in dc power systems to provide redundancy. Two or more chargers of the same voltage rating can be connected in parallel, each of them capable of powering the connected dc load and charging the battery. If a battery charger should fail during normal operation, the parallel charger can continue to supply the entire required dc load current, and maintain charge on the battery.

When two chargers operate in parallel, they normally will not share the load current equally. Since any two chargers will always have slightly different characteristics, one of the two chargers in a system will always have a slightly higher dc output voltage, and will therefore assume more of the burden of providing the necessary load current.

This instruction describes an accessory for AT Series chargers that system operators can use to force battery chargers to share load equally. The accessory consists of an interconnecting cable (EH5041-##) to provide communications between the Main Control pc boards (A1) of two (2) AT Series battery chargers.

SYSTEM REQUIREMENTS


- Both units must be AT10.1 or AT30 Series microprocessor-controlled battery chargers. This option will not work with the SCR/SCRF Series battery chargers.
- The load share option is designed to work with only two (2) battery chargers. You cannot force load sharing with three (3) or more chargers.
- Both chargers must have the same dc voltage and current rating, and have the same dc filtering level.
- Both chargers must feature "**Rev. 8**" or higher revisions on the Main Control pc board (A1).
- Both chargers must be using version "**6.00**" or later of the control program. To view the program version number, press the **LAMP TEST** button on the front panel of the charger. When you release the button, the version number is shown on the front panel display for two seconds.
- We recommend that both chargers use the same program version, since the load share option has not been tested using a different program version in each charger.
- The interconnecting cable length should be no more than 50ft (15m). A 15ft (4.6m) cable is supplied with the standard load sharing option. See "Ordering Parts" to order cable assemblies of different lengths.
- For the AT30, both chargers must have the same ac input source and the same phase rotation.

AT Series Forced Load Sharing

INSTALLING THE INTERCONNECTION CABLE

The control circuit boards in the AT Series battery chargers contain CMOS circuitry, which is sensitive to damage from static discharge. Please ground yourself before performing this procedure. You should not remove the AT Series Main Control pc board (A1) from the charger's front panel to perform this installation. All steps can be performed without any disassembly. Refer to the interconnection diagram on page 3 and follow these steps:

1. Remove all ac and dc power connected to the charger. Please note that merely turning off the charger's front panel circuit breakers (CB1/CB2), still leaves hazardous voltages at many points inside the battery charger. If possible, disconnect and lock out all external power sources. Wait a few minutes for voltages in any internal capacitors (C1/C2) to bleed off.
2. Open the front panel of the charger. On the back of the Main Control pc board (A1), in the lower right corner, locate the white 6-pin connector (J4) as shown in the figure to the right. If you cannot see the connector, verify the revision level marked on the left edge of the board. If it is lower than "Rev. 8", you need to upgrade the control card in order to utilize the forced load sharing option. Please contact your sales representative to obtain a control card upgrade (EJ1243-10), and refer to instructions (JD5012-00).



3. The AT Series forced load sharing option is normally supplied by the factory with a standard 15ft (4.5m) signal interconnection cable (EH5041-00). Other cable lengths, up to 50ft (15.2m) are also available. The cable is terminated at each end with a six-pin *male* connector which mates with the white plastic *female* connector (J4) on the Main Control pc board (A1). One end of the cable features an extra jumper in the connector, and should be identified for use with the **Secondary** charger. The other end of the cable connects to the **Primary** charger. Either charger may be selected as Primary or Secondary, but you may wish to choose the charger that is more accessible to be the Primary. The Primary charger controls the dc output voltage of both chargers.
4. You may run the interconnection cable through conduit if necessary. However, do not run the cable in the same conduit with ac or dc power wiring. Do not remove the white connector plugs in order to "fish" the cable through conduit. Maximum pulling tension is 46 lb. (20.9kg). The cable has a plenum-rated outer jacket, and passes the NFPA 262 flame propagation test. Install the cable between the chargers, and anchor it in place, before connecting it to the control cards. After the cable is in place, connect each end to the Main Control pc board, inserting the connector into A1-J4 until it is completely seated.

NOTE: External battery charger, battery, and load interconnection **power** cabling for the dc bus is **not** supplied by the charger manufacturer with the AT Series Forced Load sharing option. All user-supplied system wiring should meet National Electric Code (NEC) standards, as well as local/site codes. Confirm polarity of all dc cabling before making connections.

OPERATING CHARGERS WITH LOAD SHARING


Restore external power connections to the battery chargers, and restart according to the normal procedure in the AT Series Battery Charger Operating and Service Instructions. Close the dc circuit output breakers (CB2) first, followed by the ac input circuit breakers (CB1). After the two (2) chargers restart, the Primary charger attempts to establish communication with the Secondary. If communication is successful, the chargers behave as follows:

- The Primary charger displays the message **LS P** (Load Share, Primary) on the front panel, alternating with the normal display of output voltage and current.
- The secondary charger displays the message **LS S** (Load Share, Secondary) on the front panel, alternating with the normal display of output voltage and current.

AT Series Forced Load Sharing

- The Primary charger controls all voltage settings for both chargers. You may adjust any voltage (float, equalize, alarm settings, etc.) at the front panel of the Primary charger. The front panel of the Secondary charger won't allow any settings to be changed.
- If one charger loses ac power (or is turned off), the remaining charger returns to independent operation, whether it was originally the Primary or Secondary. For this reason, it is important to set up both chargers initially for the same operating voltages. If an alarm condition occurs, both chargers revert to independent operation for the duration of the alarm.
- In the event of a fault in the interconnection, or any other problem with communication, the chargers return to independent operation, and the front panel on each charger displays the message **E 14**, indicating the fault.
- There is a delay of up to 4 seconds for chargers to establish load sharing communication. If communication is broken (or power is lost for one charger), there is up to a 4 second delay for the other charger to resume independent operation.
- If you need to interchange the Primary and Secondary chargers, simply reverse the interconnection cable.
- The presence of the interconnection cable (and a good interconnection) forces the two chargers into load sharing. Controlling load sharing from the front panel is neither necessary nor possible.

INTERCONNECTION DIAGRAM



NOTES

1. For two (2) units to force load share, connect A1-J4 of "Primary" charger to A1-J4 of "Secondary" charger, using supplied interconnection cable (EH5041-XX).
2. J4-2 and J4-5 are factory-jumpered on the "Secondary" end of the supplied interconnection cable.
3. Battery and load inter-connection cabling not supplied with charger or load sharing option (may be supplied by battery manufacturer or other party).

AT Series Forced Load Sharing

WHEN TEMPERATURE COMPENSATION IS INSTALLED

The forced load share option is compatible with the external temperature compensation probe option (EJ5033-XX) for the AT Series. However, only the tempco probe for the Primary charger is active. If you interchange the Primary and Secondary chargers, or discontinue load sharing, be sure to check that both temperature compensation probes are working properly.

TROUBLE SHOOTING

If the AT Series Forced Load Sharing Option is installed, but the output currents of the chargers are unequal, refer to the following table.

PROBABLE CAUSE	RECOMMENDED ACTION
1. Connection cable missing or installed incorrectly.	1. Ensure that the interconnection signal cable assembly is properly installed, and that the connector for the Secondary charger has the jumper as described in the middle of page 2.
2. Incorrect connections to ac power sources.	2. Ensure that both chargers are connected to the same ac supply. For three phase input, ensure source phase rotation is the same for both AT30s.
3. Defective Man Control pc board (A1)	3. Replace the two (2) Main Control pc boards (A1) in one charger at a time to restore correct load sharing operation.

ORDERING PARTS

You may order longer interconnection cables, replacement circuit boards, or full field installation kits through your sales representative. Please use the part numbers shown in the table below.

ORDERING PART No.	DESCRIPTION
EH5041-00	15ft (4.6m) interconnection cable assembly
EH5041-01	25ft (7.62m) interconnection cable assembly
EH5041-02	50ft (15.2m) interconnection cable assembly
EJ1243-10	spare AT Series Main Control pc board (A1)
EJ5126-20 (field replacement kit)	two (2) programmed AT Series Control PC Board (A1) with one (1) 15ft (4.6m) interconnection cable assembly
EJ5126-21 (field replacement kit)	two (2) programmed AT Series Control PC Board (A1) with one (1) 25ft (7.62m) interconnection cable assembly
EJ5126-22 (field replacement kit)	two (2) programmed AT Series Control PC Board (A1) with one (1) 50ft (15.2m) interconnection cable assembly

DOCUMENT INFORMATION

Document Number: **JA5054-00**
Revision Level: **5**
Document Change Number: **21339**
Electronic Filename: **[JA5054-00.Rev-5.ATForcedLoadShareInstructions.doc]**
Last Date Saved: **[9/30/2008 12:03:00 PM]**
Last Date Printed: **[9/30/2008 12:04:00 PM]**

ON-LINE AVAILABILITY

An electronic version of this manual is available online at <http://www.ATSeries.net/JA5054-00.pdf>, along with standard drawings for the AT10.1 and AT30 Series Battery Chargers. Saved in Adobe Acrobat Portable Document Format (PDF), they are readily available for downloading and printing.