



RECOMMENDED PROCEDURE :

- 1) DEENERGIZE AND LOCK OUT ALL AC AND DC VOLTAGE SOURCES TO THE AT10.1. CHECK WITH A VOLTMETER BEFORE PROCEEDING.
- 2) DRILL OUT TWO (2) 0.312in / 7.9mm DIAMETER PILOT HOLES AS SHOWN AND CLEAN OUT METAL FILINGS.
- 3) INSTALL LOCK AS SHOWN TO RIGHT.
- 4) CHECK YOUR WORK.
- 5) RE-ENERGIZE THE AT10.1.

BILL OF MATERIAL : EI0215-00			
ITEM NUMBER	PART No.	DESCRIPTION	QUANTITY PER ASSY
①	PE0386-00	MASTER PADLOCK W/ ADJ. SHACKLE	1
	JA0108-00	CUSTOMER INSTRUCTIONS	1

				 THIRD ANGLE PROJECTION	TITLE AT10.1 SERIES BATTERY CHARGER PADLOCK CUSTOMER INSTALLATION INSTRUCTIONS			
				DRAWN BY <i>WAH</i> 050393 APPROVED WAH 050393	DRAWING No. JA0108-00		REV 1	B
1	21590	040209	ND	UNLESS OTHERWISE NOTED DIMENSIONS ARE IN INCHES. TOLERANCES ARE:	SCALE	NTS	PART No. JA0108-00	SHEET 1 OF 1
0	9736	042293	WAH					
REV	ECN No	DATE	APP					